


BC-120, installation


Batteries

or

Power adapter



4x 1.5V C-size battery (excl.)






or

6V DC 300mA adapter (incl.)








BC-120 in cradle



NOT OK


BC-120 on crib




Service 	Help 		Alecto [®]  +31 (0) 736411355
--	--	---	---




BC-120, function




Dia's verwisselen
Changer dia
 Dia's umtauschen
Exchange slides
 Troca slides



Scherpstellen
Réglage précise
 Scharfeinstellung
Adjusting sharpness
 Ajustar nitidês



Instellen projectie-snelheid
Réglage vitesse
 Set projection-speed
Einstellen Geschwindigkeit
 Ajustar velocidade



VOX ON OFF


Uit
 Aan
 Geluid-
 gestuurd
 (na 5 sec)

Hors
Marche
Activation
automatique
 (après 5 sec)

Off
 On
 Voice-
 activated
 (after 5 sec)

Aus
 Ein
 Reagiert bei
 Geräusch
 (nach 5 sec)

Off
 On
 Activação
 de voz
 (após 5 segundos)




Muziek
 Licht
 Muziek + Licht
 Eigen stem

Musique
Lumière
Musique + lumière
Propre voix

Musik
 Licht
 Musik + Licht
 Eigenen Stimme


Music
Light
Music + Light
Your own voice

Musica
 Luz
 Musica + Luz
 Própria voz




Instellen speeltijd
Réglage temps de jouer
 Spielzeit einstellen
Set play-time
 Tempo de leitura ajustável

			continu
		2 min	
		5 min	
		10 min	
		12 min	
		15 min	
		17 min	




Selecteren babygeluiden en slaapmuziekjes
Sélectionner des bruits de bébé et des chansons de sommeil
 Selektieren Babygeräusche und Schlaflieder
Select sounds and lullabies
 Sons e canções de embalar naturais

Opnemen eigen stem
Enregistrer propre voix
 Aufnehmen der eigenen Stimme
Record your own voice
 Grava a sua própria voz



①



②



③ > 2 sec.:



④



8 sec. max



volume

⑤